# CAL MAXVU RAIL

Temperature Limit Device Datasheet



## Overview

MAXVU Rail temperature and process limit is a device that's easy to install and fast to setup with an easy to read OLED display.

MAXVU Rail provides an affordable solution where secondary temperature limit protection is required, it offers a universal input and up to 3 outputs.

#### **Specification**

#### Input Thermocouple J, K, C, R, S, T, B, L, N. RTD 3 Wire PT100 **DC Linear** 0 to 20mA, 4 to 20mA, 0 to 50mV, 10 to 50mV, 0 to 5V, 1 to 5V, 0 to 10V, 2 to 10V. Scalable -1999 to 9999, with adjustable dec point Accuracy Thermocouple ±0.25% of full range ±1 LSD (±1°C for thermocouple CJC). PT100 ±0.25% of full range, ±1LSD, Linear ±0.25% of full range, ±1LSD. Sampling 4 per second Impedance >10M $\Omega$ resistive, except DC mA (5 $\Omega$ ) and V (47KΩ) Sensor Break <2 seconds (except zero based DC ranges), high Detection alarms activate for T/C, RTD and mV ranges, low alarms activate for mA or V ranges **Digital Input** Reset Alarm. Volt Free or TTL compatible, 24VDC LIMIT SPDT Form C, AL1 / 2 SPST Form A Relay relay; current capacity 2A at 250V. >150,000 operations at rated voltage/current, resistive load SSR Drive capability >10V DC @ 20mA Linear DC 0 to 20mA, 4 to 20mA, 0 to 5V, 0 to 10V or 2 to 10V Current Output 500 $\Omega$ max, Voltage Output 500 $\Omega$ min Serial Communications 2 Wire RS485, 1,200 to 38,400 baud, Modbus RTU



#### At a Glance

- DIN rail mounted
- Universal input
- Up to 3 outputs
- Digital Input
- RS485 communications option
- Fast configuration
- Clear OLED display
- 22.5mm module width


#### **Key Features**

- Text / Icon matrix display
- Quick setup menu with main configuration parameters
- Thermocouple, PT100 or linear DC sensor input
- Up to 3 outputs; relay, SSR or Linear DC
- Isolated Digital input
- Limit alarm plus warning, high/ low or deviation
- 3 button operation
- 3 status LEDs
- Front panel configuration or via PC configuration software
- RS485 Modbus RTU communications


#### **Operating and Environmental**

Temperature & RH Altitude Power Supply	0 to 55°C (-20 to 80°C storage), 20% to 95% RH non-condensing <2000M 100 to 240V ±10%, 50/60Hz, 9VA(mains powered version) 24V DC/AC +10%/-15%, AC 50/60Hz, 5W (low voltage version)
Enclosure Protection	IP20
Standards	CE, UL, cUL & FM
EMI	Complies with EN61326-1 (Susceptibility & Emissions)
Safety Considerations	Complies with EN61010-1 & UL61010-1
	Pollution Degree 2, Installation Category II
Weight	0.20kg excluding packaging

#### **Dimensions**



### **Ordering Code**



#### Accessories

#### MAXVU Configuration software

For PC setup MAXVU configuration software is available free of charge from www.west-cs.co.uk.

A USB configuration cable is also available from your local WCS distributor.



MAXVU configuration software is simple to use for fast set up of MAXVU devices.



Set-up wizard simplifies the set-up further.

Provides step-by-step guidance to device configuration with detailed assistance on each setting.

Setting be	*		1.444
Sec. 1	A 4		**
- he	A	÷.	6.98
Second Inc.	14		10.000
And Personnel			1.00
The later.	And 1 (1997) 1 (1997) 1 (1997)	2	
Contract of	Le.	1	
	1		
	11, 11,	21	Marco and American Statements of the second statement

Clear and logical side tabs make it easy to find parameter settings in tabular form.

Simple icon driven taskbar along top for all main functions



Each parameter shows current setting and can easily be changed by drop-down menus or entering values.

Allowable setting range is shown for guidance.

A useful help box provides additional assistance.

#### Contact



Email: Website: inquiries@west-cs.com www.west-cs.com



Telephone: Fax: +1 800 866 6659 +1 847 782 5223



Address:

1675 Delany Road Gurnee IL 60031-1282 USA

